



Hawse Fairlead Part Number 10102

How to install the Grimm OffRoad Hawse Fairlead part number 10102.

Written By: AJ Smith



**TOOLS:**

- [15mm Wrench](#) (1)
- [6mm Allen Key](#) (1)

**PARTS:**

- [Grimm Offroad Hawse Fairlead](#) (1)
- [M10x1.5x50mm Button Head Screw](#) (2)
- [M10 Washer](#) (2)
- [M10x1.5 Flange Nut](#) (2)

Step 1 — Included Parts



⚠ Verify that all parts shown in the picture are present.

Step 2 — Remove Existing Fairlead (If Equipped)



- Remove the existing fairlead if there is one to be replaced.

Step 3 — Route Winch Line Through Fairlead



- Remove any existing hooks from winch line so that the line may be passed through the fairlead.
- Install one washer and button head screw through the fairlead, and then pass the winch line through the fairlead.
- Insert the screw through the fairlead mounting hole and let the fairlead hang.
- Install a flanged nut on the backside of the screw and thread it on a few turns.

Step 4 — Tighten Fairlead Hardware



- Insert hardware through the other side of the fairlead and install nut on backside.
 - Snug hardware on each side. With hardware snug, position the fairlead so that the winch line cannot contact the fairlead mount or bumper mount edges.
- i** With the fairlead correctly positioned, torque hardware to 25 lb-ft [34 Nm].

Step 5 — Torque Hardware



- Install hook on winch line and re-spool the winch line.

⚠ Recheck hardware and winch line periodically to prevent failure.

Installation is complete!

With any modified vehicle, or any vehicle used offroad, it is a good idea to check bolt torques periodically and visually inspect components regularly.