



Jeep JK A Pillar Light Mounts Part Number 10247

How to install the Grimm OffRoad Jeep JK A Pillar Light Mounts part number 10247.

Written By: AJ Smith





TOOLS:

- [T40 Torx Driver](#) (1)
- [Various Other Tools Depending On Lights Mounted](#) (1)




PARTS:

- [Jeep JK A Pillar Light Mount - Left](#) (1)
- [Jeep JK A Pillar Light Mount - Right](#) (1)

Step 1 — Included Parts



 Verify that all parts shown in the picture are present.


Step 2 — Remove Windshield Frame Bolts



- The mounts use the two factory torx bolts at the base of the windshield frame.
- Using a T40 torx driver, remove the two bolts.

Step 3 — Install Light Mounts



- Identify the left and right side brackets. The mounts can only fit one way, see images.
 - Place the light mounts over the windshield frame holes and re-install hardware.
-  Torque hardware to 15 lb-ft [20Nm]

Step 4 — Install Lights



- Install lights onto light mounts.
- Follow wiring instructions provided by the light manufacturer.

Installation is complete!

With any modified vehicle, or any vehicle used offroad, it is a good idea to check bolt torques periodically and visually inspect components regularly.